

NOTES:

- 1. REQUIRED ON ALL PIPES WHERE SLOPE EQUALS 20% OR GREATER.
- 2. PROVIDE EROSION CONTROL AS REQUIRED BY JURISDICTIONAL AUTHORITY.
- 3. DO NOT USE ANCHORS IN SANDY MATERIAL, UNLESS DIRECTED OTHERWISE BY THE DISTRICT.
- 4. TIGHT WRAP PIPE WITH 8 MIL. PLASTIC ON DI.
- 5. ANCHOR PLACED ON THE LOWER SIDE OF THE BELL.
- 6. FOR HDPE, BUTT FUSE RING TO OUTSIDE OF PIPE DIRECTLY ABOVE ANCHOR LOCATION. FOR C-900, INSTALL A UNIFLANGE DIRECTLY ABOVE OR IN ANCHOR.

MINIMUM ANCHORAGE SPACING:

NOT OVER 36 FEET CENTER TO CENTER ON GRADES 20 PERCENT AND UP TO 35 PERCENT.

NOT OVER 24 FEET CENTER TO CENTER ON GRADES 35 PERCENT AND UP TO 50 PERCENT.

NOT OVER 16 FEET CENTER TO CENTER ON GRADES 50 PERCENT AND OVER.

